
## **KINGSTON**

## INSTALLATION INSTRUCTIONS Angle Stop

## Instructions:

- Apply thread sealant tape to threads (1).
- 2. Screw valve body (2) onto pipe (3) and hose (4).
- 3. Stop any leaks by tightening nuts slightly.





Failure to follow all directions may cause leaks which may result in water damage

www.kingstonbrass.com

TOLL-FREE CUSTOMER SERVICE: 1-877-2-KBRASS TECHNICAL SUPPORT E-mail: service@kingstonbrass.com 12775 Reservoir Street, Chino, CA 91710