
Change Pull-out Sprayer Tube

Repair Tool:



Step 1: Use allen wrench (3/32" size) to loosen the set screw and pull out the spout





Step 2: Use 13mm Wrench to remove the pull-down tube

The white Teflon C-clip also needs to be taken out if left inside the body





Step 3: Remove the defective tube and put in a new tube inside the spout









Step 5: Use wrench to turn and tighten up the hex nut all the way down to connect the tube with the body



Step 6: Adjust and make sure the upper C-clip's small hole is to align with set screw hole of the body





Step 7: Tighten up the set screw with allen wrench



