Repair Instruction Manual for KSRP2331D Diverter		
Tools	Needle nose pliers  10mm Hex allen wrend	ch Adjustable Wrench
Repair part	Diverter parts(# KSRP2331D)	
Step	Photo	Description
1.		Use wrench to loosen the adapter beneath the spout by turning counter-clockwise and then carefully pull out the spout from the faucet body.
2.		Use a 10mm Hex Allen wrench to loosen the diverter inside the faucet body by turning counter-clockwise.

