




Assembly Instruction:


Remove Old Spout by turning in a counterclockwise direction.


FOR 1/2" COPPER PIPE CONNECTION:


Tools Required: Hex Wrench (Included)


- 1. The length of copper pipe (B) from the finished wall should be at least 1" to maximum 2".
- Trim the end of copper pipe. Chamfer the pipe end (B) and remove all burrs to avoid damaging the O-ring.











FOR 1/2" MALE PIPE CONNECTION WITH THREADED END:

- 1. Wrap the threads of the wall nipple (H) with Teflon tape.
- 2. Thread the spout (A) to the wall nipple (H) by manually turning in a clockwise direction.

FOR 1/2" MALE THREADED CONNECTION:

- 1. Wrap male threads of the wall nipple (F) with Teflon tape.
- 2. Assemble the reducing adapter (G) to the wall nipple (F) with Teflon tape.
- 3. Assemble the extension nipple (E) to the reducing adapter (G) until the adapter is completely tightened and covered.
- 4. Wrap the male threads of the extension nipple (E) with Teflon tape. Thread the spout (A) to the extension nipples (E) by manually turning in a clockwise direction.

FOR 3/4" MALE THREADED CONNECTION:

- 1. Wrap the male threads of the wall nipple (I) with Teflon tape.
- 2. Assemble the extension nipple (E) to the 3/4" wall nipple (I) until the nipple is tightened and covered.
- 3. Wrap the male threads of the extension nipple (E) with Teflon tape.
- 4. Thread the spout (A) to the extension nipples (E) by manually turning in a clockwise direction.

Note: To ensure the Teflon tape perform properly disregarding the tape thickness, it is recommended to wrap 3 times around or more.



www.kingstonbrass.com

TOLL-FREE CUSTOMER SERVICE: 1-877-2-KBRASS TECHNICAL SUPPORT E-mail: service@kingstonbrass.com 12775 Reservoir Street, Chino, CA 91710