
KINGSTON

KITCHEN & BATH

Adjustable Slide Bar

Installation


Parts:



ACAUTION

Failure to follow all installation directions may cause product to detach from the wall and cause serious injury www.kingstonbrass.com
TOLL-FREE CUSTOMER SERVICE: 1-877-2-KBRASS
TECHNICAL SUPPORT E-mail: service@kingstonbrass.com
12775 Reservoir Street, Chino, CA 91710

Need Tools:




Legal Disclaimer:

This bar is not to be used as a grab bar and it is not intended to support weight.


Before you begin, identify the appropriate area to install this slide bar, proper location should be above 48" from the floor (as per ASTM F446).

It is recommended that slide bar to be mounted directly to the structural framing of your home. If necessary, cross bracing can be installed to provide adequate support.

Installation:




1. Assemble slide bar and position at the desired location.



2. Mark the position of the mounting screw by inserting a pencil through the center of the end post.



3. Remove slide bar and drill a small hole, insert plastic anchor until it is flushed with the surface of the wall.



4. Attach both upper and lower bases by inserting the enclosed screws through the brass fitting preinstalled on the escutcheon, insert the slide bar posts onto the brass fitting, and secure by threading the set screw, press cover button in place,

KINGSTON

KITCHEN & BATH


INSTALLATION INSTRUCTIONS Shower Supply Elbow


Instructions:


- 1. At the desired location, drill a hole Ø7/8" on the wall.
- 2. Install 1/2-NPT male thread pipe protruding from the wall 1/2" to 5/8".
- 3. Apply Teflon tape onto the threads.
- 4. Apply silicone around the neck of shower supply elbow and the back of flange.
- 5. Insert flange and thread the shower supply elbow onto the 1/2-NPT male thread pipe.

Do Not Over Tighten The Thread Connection.

Wipe off excess silicone around the flange.







www.kingstonbrass.com
TOLL-FREE CUSTOMER SERVICE: 1-877-2-KBRASS
TECHNICAL SUPPORT E-mail: service@kingstonbrass.com
12775 Reservoir Street, Chino, CA 91710







KINGSTON


KITCHEN & BATH

INSTALLATION INSTRUCTIONS Hand Shower & Shower Hose










NOTICE

Failure to follow all directions may cause leaks which may result in water damage

www.kingstonbrass.com
TOLL-FREE CUSTOMER SERVICE: 1-877-2-KBRASS
TECHNICAL SUPPORT E-mail: service@kingstonbrass.com
12775 Reservoir Street, Chino, CA 91710

Installation Steps for Hand Shower:

- 1. Remove the old hand shower from the hose by turning it counter-clockwise.
- 2. Check the original washer on the hose adapter for any damage; replace if necessary.
- 3. Clean the washer and remove any debris from inside the hose adapter.
- 4. Reinsert the washer into the hose adapter, ensuring it sits flat against the bottom.
- 5. Hand-tighten the new hand shower onto the hose adapter by turning it clockwise. Ensure it's secure but do not over-tighten.
- 6. Turn on the water to check for leaks around the hose adapter. If leaks are found, loosen and retighten the hand shower or replace it with a thicker sealing washer.



Installation Steps for Shower Hose:

- 1. Remove the Old Hose, Turn the hose adapter counterclockwise to detach it from the outlet.
- 2. Insert the enclosed rubber washers into each end of the new shower hose, ensuring they are seated fully inside the adapters.
- 3. Hand-tighten the end of the hose with the faceted adapter into the outlet. Turn on the water for at least 30 seconds to flush out any debris from the line. Check for leaks at the connection.
- 4. Hand-tighten the other end of the hose to the hand shower. Turn on the water to check for any leaks, re-tighten if necessary.

